



Action Sports Equipment Pty Ltd.

72 Silverwater Rd, Silverwater, NSW, Australia, 2128

Parts & Service Enquiries: 1800 465 070 (Australia); 09 488 4750 (New Zealand)

Or email: service@actionspares.com.au

Sales Enquiries: 1800 777 137 (Australia); 09 488 4750 (New Zealand)


Or visit our website: www.actionsports.com.au

S000193 - Junior Jumper, Blue

S000426 – Junior Jumper, Pink

S000427 – Junior Jumper, Green

Assembly, Installation, Care, Maintenance and Use Instructions



IMPORTANT

Please read and retain this manual as it will assist with identification for parts and service.

Read this manual prior to assembling and using this product.

This Product is for Domestic Use Only.

- Warning -

Adult assembly is required

For children age 12 months and up

This item is subject to a maximum user weight of 35kgs.

Always use under adult supervision

Do not allow more than one person on the trampoline at a time.

Thank you for purchasing the Junior Jumper. This rebounder type trampoline is a great addition to your child's exercise routine. It assists in improving coordination, balance & agility, trimming & toning, and is a fun way to encourage fitness activity in young children. Please read the following information before using your Junior Jumper.

- Safety Notice -

- Children should use only with mature, knowledgeable supervision.
- Place trampoline on level surface for use. Make sure floor area around and under trampoline is clear of objects and there is adequate overhead and lateral clearance around trampoline. Do not place trampoline near walls, structures, play areas, furniture or other exercise equipment.
- Use in well lighted area with level surface. This trampoline is designed to be used by one person at a time.
- Inspect before each use. Make sure frame pad is in place and legs are firmly seated. Replace any worn, defective, damaged or missing parts.
- The weight limit for your Junior Jumper is 35kgs. Do not allow persons exceeding this weight to use this trampoline.
- Wear correct footwear such as walking, running or cross-training shoes that fit well and provide adequate support. Insure footwear provides good traction. It is not recommended for jumper to be barefoot when using trampoline. Wear appropriate clothing when exercising. Do not wear loose clothing that could become caught in the trampoline.
- The surface of the bed should be dry when used. Do not stand, step or sit on the frame pad, the springs or the trampoline frame.
- Maintain balance when mounting and dismounting the trampoline. Stop exercise movement when mounting and dismounting. Loss of balance can result in a fall or serious injury. Bounce in the centre of the trampoline bed.
- Do not attempt any gymnastics or acrobatic maneuvers. Do not jump from floor onto the trampoline or from trampoline bed to floor or other surface.
- Always use this trampoline in accordance with this manual.
- Store the trampoline indoors in a dry place. Secure the trampoline from unauthorized and unsupervised use.













ANY QUESTIONS OR CONCERNS


PLEASE CALL CUSTOMER SERVICE

Freecall 1800 465 070 or Standard Call 09 488 4750 (New Zealand)


Or email: service@actionspares.com.au

Parts Supplied

Ref	Description	Illustration	Qty
A	Left Handle Tube		1
B	Right Handle Tube		1
C	Leg Tube (1) (scoop tube)		3
D	Leg Tube (2)		1
E	Mat with Foam Padding		1
F	Bungee Cord		1
G	Hook		1
H	Rubber End Caps		4
I	Sleeve		1
R43	M6 x 43mm Hex Bolt		6
R47	M6 x 47mm Hex Bolt		2
U2	M6 Washer		16

R6	M6 Dome Nut		8
----	-------------	---	---

Tools included in the Item



Wrench



Allen Key

Assembly and Installation Instructions

Step 1: Select a clear area and lay out the frame legs on the floor.




Figure 1

Step 2: Slide the handle cover Sleeve (I) onto the Left Handle tube (A).




Figure 2

Step 3: Connect the Left Handle tube (A) and Right Handle tube (B) together. Then move the handle cover Sleeve (I) so it covers the foam on both handle tubes (A) & (B).




Figure 3

Step 4: Connect the frame together with the handle as shown in the below diagram.






Figure 4

Before tightening screws, it is important to ensure the metal end of the Handle tubes, leg tubes and scoop tubes are in direct alignment and at even height. Misalignment of the legs prior to tightening may lead to the unit being unstable.



Please be careful that the scooped or concave side of Leg Tube C should face to the Handle (A & B). Ensure the leg frame and handle are in position and are stable on ground. Tighten the bolts, washers and nuts accordingly.

Finally, push 4 rubber end caps (H) over each of the four assembled legs.



Step 5: Place the Mat & Foam Padding (E) onto the Frame. Make sure the padding panel that with two long Velcro tie-downs cover Leg Tube D.




Figure 5

Step 6: Fold up the padding. Thread the bungee cords through the eyelet loops and evenly over the frame.




Figure 6

Step 7: Make sure the bungee cord is threaded through every eyelet loop and over the whole way around the frame. Connect the ends by hooking the carabiner clip to the other end that with a hole on it as shown in Fig 7.

Check again the bungee cord again to make sure it goes around evenly around the frame in both spacing and tensions.




Figure 7

Step 8: Unfold the padding to cover the whole frame. Secure the front padding onto the frame with the Velcro tying straps as shown in Figure 8.




Figure 8

Step 9: Secure the back padding onto the frame with sewn in Velcro patches.




Figure 9

Maintenance Instructions:

- Inspect the trampoline before each use and replace any worn, defective, or missing parts.
- The product must not be used until properly and fully installed and checked.
- To avoid damage to the Trampoline, do not allow pets or other animals on the Trampoline. Their claws and teeth can damage the mat of the trampoline.
- Disassemble and store the product when it is not in use.

Trampoline Limited Warranty

ACTION SPORTS warrants its trampoline products to be free from defects in material and workmanship under normal use and service conditions.

The various components of the trampoline are warranted against defects and workmanship for the time periods specified as follows:

Steel Frame and Jumping Mat.	2 years
All Other Materials	6 months

All warranty coverage extends only to the original retail purchaser from the date of purchase. ACTION SPORTS' obligation under this Warranty is limited to replacing or repairing, at ACTION's option, the product or parts therein. Any enquiries relating to warranties or spare parts must be directed to our **Freecall 1800 465 070 or Standard call 09 488 4750 (New Zealand)**. For efficient processing of your enquiry please have relevant date of purchase, retailer name you purchased the item from and the brand on the product. This warranty does not extend to any damage to a product caused by abuse, improper or abnormal usage (as detailed in this instruction manual), or repairs not provided by ACTION. Nor does this warranty extend to products used for commercial or rental purposes. This warranty does not cover ordinary wear, tear and weathering, failure to follow directions, improper installation, improper maintenance or acts of God (such as damage caused by storms, lightning and by snow or ice). No other Warranty beyond that specifically set forth above is authorised by ACTION.

Our sales and service centre has been set up to provide assembly assistance, replacement parts and accessories, and to efficiently handle all warranty related matters.

Freecall **1800 465 070 (Australia) or email service@actionsports.com.au**
Standard Call **09 488 4750 (New Zealand).**

Opening hours: 9am – 4:30pm Monday to Friday (excluding Public Holidays)
9am – 3pm Saturday

www.actionsports.com.au